

Make your life easier



Image

- Photo accessories - Camera bags



Reflex camera bag with high density foam to protect your camera. Mesh pocket inside for your accessories (memory cards, cables, battery...)

BOX CONTENTS









Characteristics



reflex cameras



Nylon, polyester, PVC

Packing: 2 Net weight (g): 202
Weight with packaging (g): 212
Product size (cm): 19,5x19x13,5 Packing size (cm): 19x13.5x19.5



