

Make your life easier



Image

- Photo accessories - Camera bags



Reflex camera bag with high density foam to protect your camera. Mesh pocket inside for your accessories (memory cards, cables, battery...)

BOX CONTENTS









Characteristics









reflex cameras



Nylon, polyester, PVC



Packing: 2 Net weight (g): 202 Weight with packaging (g): 212 Product size (cm): Packing size (cm): 19x13.5x19.5



